

Quick Programming Guide

For Artesian Spas(South Seas)

To set the mode on your hot tub

First press the warm button, and then the mode button. One right after the other. The tub should display Ecn, Slp, or Std. I explain what these mean in the (Hot Tub Programming Guide). In any case keep pressing the warm button and then the mode button to cycle through the settings until it says "Std". Once it says "Std" then hit the mode button one more time at the end. You will know it's in standard mode when it just reads the current temperature.

To set the filter cycle

First press the warm button and then the Jet button. One right after the other. The tub should display FIL2, FIL4, FIL6, FIL8 or FILC. Once one of these are displayed keep pressing the warm button until you get it to say FIL2. Once it does then hit the Jet button one more time. You'll know it's programmed because it will go back to reading the temperature.

That's it, you all done. Just set the temperature with the warm or cool button and the tub will run until it reaches the temperature you set it for. The tub will always read what the current temperature is at.

One last thing. If anyone gets in the tub and they change the temperature they have to wait about 3 seconds before hitting any other buttons otherwise they may enter a programming mode and change your settings by accident. Also whenever you shut the spa off by the breaker say to drain and clean. When you power it back up, it will go back to the last settings you had it set for previously. It has a memory so you won't have to reprogram it.